

Corner Post Installation Instructions

- Ensure corner posts are plumb
- Allow 1/4" gap between top of post and eave or soffit
- Position nail at top of uppermost slot on both sides of corner post
- Center nail remainder of corner post every 8" to 12"
- Leave gap of 1/32" between nail heads and nail slots
- Corner post should extend 3/4" below starter strip
- If overlapping, notch 1" of nail flange from bottom of top piece, overlap 3/4" allowing 1/4" for expansion/contraction between corner post
- Corner post should always expand downward; do not rest on porch

